

TECHNICAL DATA

Fluke TRM50 Coaxial Feed-through BNC Male to BNC Female Cable Terminator



Key features

- 50 ohm coaxial feedthrough
- Provides proper cable termination
- Prevents coaxial cable reflections

Product overview: Fluke TRM50 Coaxial Feed-through BNC Male to BNC Female Cable Terminator

Fluke TRM50 Coaxial Feed-through Terminators come standard with Fluke 190-502-III and 190-504-III ScopeMeter Portable Oscilloscopes and are compatible with other [Fluke ScopeMeter 190 Series III](#) or Series II Test Tools. TRM50 Cable Terminators help ensure proper termination of coaxial signal cables such as the [Fluke PM9091 50 Ohm Coaxial Set](#), and [Fluke PM9092 50 Ohm Coaxial Cable Set](#), when used with high frequency signals and signals with a fast (short) risetime. The TRM50 also helps to prevent signal reflections on the coaxial cable that might distort signal fidelity.

Specifications: Fluke TRM50 Coaxial Feed-through BNC Male to BNC Female Cable Terminator

Connector type	BNC-male to BNC-female
Impedance	50 Ohm
Impedance accuracy	± 1%
Frequency range	up to 500 MHz
Voltage ratio	1:1 (output/input)
Voltage Standing Wave Ratio (VSWR)	< 1:1.15 at 500 MHz
Max signal voltage	7 Vrms
Max Voltage over ground	1000 V CAT III
Max power	1 W
Overall length	53 mm (2.1 in.)

Ordering information



Fluke TRM50 Coaxial Cable Terminator

Fluke TRM50 Coaxial Cable Terminator

Includes:

- Two TRM50 Coaxial Cable Terminators



Fluke. *Keeping your world up and running.*®

Fluke Corporation
PO Box 9090, Everett, WA 98206 U.S.A.

For more information call:
In the U.S.A. (800) 443-5853
In Canada (800) 36-FLUKE
From other countries +1 (425) 446-5500
www.fluke.com

©2024 Fluke Corporation.
Specifications subject to change without notice.
10/2024

**Modification of this document is not permitted
without written permission from Fluke Corporation.**